

100 Bayshore Drive, Bath, ON K0H 1G0

Tel: 613-352-3478 Fax: 613-352-5209

Email: info@loyalistcovemarina.com

www.loyalistcovemarina.com

Mast Stepping (Up) Explained

- * The Standard Mast Fee includes the boom truck, boom truck operator and one LCM staff to assist for 1/2 hour maximum for the following service: (additional time is \$125.00 per 15 Minutes)
- * The LCM staff will take the customer's mast from the storage rack to saw horses.

The customer will unpack and rig the mast to be ready for stepping.

Make sure that the masthead/steaming light is facing up to the sky while on the saw horses before putting your spreaders back on - Otherwise additional lift is charged

When the customer has the mast ready to step, please let the LCM staff know. When instructed, the customer will bring the boat to the mast dock.

* The LCM staff will rig up the mast, then raise the mast and place on the boat.

The customer will then assist to attach forestay, backstay and shrouds.

* When finished the LCM staff will disconnect rig from the mast.

The customer will move boat back to assigned slip to finish mast.

NOTE: If you require assistance rigging the mast before it is stepped OR require the LCM staff to do the complete mast preparation, please let the office know to schedule so we can provide this service.

Mast Unstepping (Down) Explained

* The Standard Mast Fee includes the boom truck, boom truck operator and one LCM staff to assist for 1/2 hour maximum for the following service: (additional time is 125.00 per 15 Minutes)

The customer should remove all sails and boom to have the mast ready to come off.

Deck Step Mast – All shrouds must be loose upon arrival to mast dock.

Keel Step Mast – All shrouds must be loose & pins pulled upon arrival to mast dock.

When instructed, the customer will bring the boat to the mast dock.

* The LCM staff will rig up to the mast and hold in place.

Once the rig has the weight of the mast the customer will disconnect the shrouds, forestay, backstay and any electrical connections.

* The LCM staff will then lift the mast and set on sawhorses.

The customer will move boat back to assigned slip.

On the day a mast is unstepped, the customer must remove the spreaders and pack up the mast for storage. If a mast is not packed up on same day, there will be an additional charge for LCM staff to pack up.

* The LCM staff will move the mast from the sawhorses to the storage racks.

NOTE: If you require assistance preparing the mast to unstep OR require the LCM staff to do the complete mast preparation, please let the office know to schedule so we can provide this service.

August 2023